

Adhesive Mounting Instructions



-> Verkleben? Kinderleicht!
mit unserer Transferfolie
gelingt es
schnell und sauber!

Sticking made easy!

Thanks to our transfer film, it's quick and clean!

Important Notes:

- If the sticker consists of several parts, it may come with an additional transfer foil (rough, milky, or clear, not contour-cut). This foil is only used during application and is removed afterward. Underneath, the sticker will appear as ordered.
- Large stickers may be rolled or partially folded during packaging-this can create waves that will disappear with professional mounting. The sticker itself does NOT have any creases.
- Always read the complete instructions before starting. There are two methods available:
 - 1) Dry bonding or

2) Wet bonding (recommended for large motifs/surfaces)

Surface Preparation:

- The surface must be free of dust, grease, silicone, and latex.
- Remove any knobs or handles before application on furniture or doors.

Mounting Type 1: Dry Bonding

STEP 1: Squeegee (only if transfer film is used)

- Fold the included "environmental squeegee" as instructed.
- Use it to press the transfer foil firmly onto the sticker.
- Then turn the sticker over so the transfer foil is on the bottom.

STEP 2: Remove Backing Paper

- Peel off the white backing paper slowly from one corner.
- If the sticker sticks to it, press it again with the squeegee and repeat.

STEP 3: Stick the Sticker

- Hold the sticker by the top corners under tension and align the top edge to the surface.
- Use a fabric-wrapped squeegee to prevent scratches.
- Smooth from top to bottom and center to edges.
- If necessary, lift and reapply parts for better alignment.
- Finally, remove the transfer foil carefully.

STEP 4: Final Touches

- Press down any loose parts of the sticker with your finger.

STEP 5: Reattach Handles/Knobs

- Pierce a hole in the sticker where the screw goes before screwing in.

Mounting Type 2: Wet Bonding

Important:

- This method extends drying time.

What you need:

- Spray bottle with water (optional: add 1 drop of dish soap per liter for large stickers).

STEP 1: Squeegee (if transfer film is used)

- As in dry bonding, press the transfer foil firmly to the sticker using the squeegee.

STEP 2: Remove Backing Paper

- Peel off the backing paper slowly. Repeat step if parts stick.

STEP 3: Wet Gluing

- Spray water onto both the adhesive side of the sticker and the surface.
- Place the sticker with the transfer film on the desired spot.
- Start from one corner and adjust gradually.
- You can reposition if needed-adhesive remains workable longer.

STEP 4: Re-squeegee

- Once in place, press out the water with the squeegee from center to edges.
- Wrap cloth around the squeegee to prevent scratches.
- Smooth edges, and press with more pressure until no bubbles or water remain.
- Remove the transfer foil carefully.
- After a short time, press again to ensure adhesion.
- You may pierce small bubbles with a needle to remove them.
- Let the sticker sit for a day to allow the adhesive to fully cure.

STEP 5: Reattach Handles/Knobs

- As with dry bonding, pierce a small hole before reinserting the screw.